



# 2022+ SUBARU BRZ/TOYOTA GR86 MUD FLAP INSTALLATION INSTRUCTIONS

Manufacturer warranty covers material defects on new, never installed parts. Once installed, all mud flap replacement part costs are the responsibility of the vehicle owner. Caution against blind spots during parking. Avoid curbs and excessive compression to the flaps. Check stock and aftermarket wheel/suspension clearances.

INSTALLATION QUESTION? FOR REPLACEMENT PART QUOTES, SEND FLAP RECEIPT OR PHOTO 
www.rallyarmor.com/support Recommended Tools Low-profile offset, ratcheting, flat & Phillips screwdrivers, pick.

ONLY install on even surface using hand tools, not powered tools. AVOID OVERTIGHTENING HARDWARE.

**ABOUT OUR STANDARD IN MUD FLAPS** Polyurethane is a high grade plastic that may feature minor surface layer marks. These are visual variations that don't affect flap construction or performance. Most matte away as the material ages naturally.

MF99 KIT CONTENTS CONFIRM ALL PARTS AND QUANTITIES BEFORE INSTALLATION			
MUD FLAP	KIT PN: MF99 SEE PAGE 4 DRAWINGS	PART DESCRIPTION	QUANTITY
MF99-LF		LEFT FRONT	1
MF99-RF		RIGHT FRONT	1
MF99-LR		LEFT REAR	1
MF99-RR		RIGHT REAR	1
BRACKET PI			
BMF80-RE	b	BRACKET FRONT	2
BMF99-LR		BRACKET LEFT REAR	1
BMF99-RR		BRACKET RIGHT REAR	1
	KIT PN: HMF99 SEE PG 4		
.75SP		SPACER	2
1SS#8		SCREW	2
1.5SS#8		LONG SCREW	8
BLKNUT	•	NUT	2
EXPANCH	S.	EXPANSION ANCHOR	10
HXBLT		PLASTIC BOLT	2
SMF29-1	6	FOAM SPACER	6
SMWASH		WASHER	20
SSLNUT	0	LOCK NUT	8

## IMF99



### 2022+ SUBARU BRZ/TOYOTA GR86 MUD FLAP INSTALLATION INSTRUCTIONS

FRONT FLAP Bracket/Hardware 1 x Flap → 1 x BMF80-RE; 1 x 1SS#8; 3 x 1.5SS#8; 4 x EXPANCH; 3 x SMF29-1; 5 x SMWASH; 1 x


SSLNUT

To gain access inner wheel well area, turn steering wheel towards installation side. **Do not fully tighten fasteners until mud flap is completely aligned to vehicle.** 


FIGURE A Remove factory fasteners 1 - 4.


**FIGURE B** To expand EXPANCH, insert a pick  $\frac{1}{2}$ " into mounting hole. Install EXPANCH into mounts 1-3, then replace liner. Place EXPANCH into mount 4.


FIGURE C Wipe liner clean before installing SMF29-1 over 1 - 3.



**FIGURE D** Install SMWASH & 1SS#8 into BMF80-RE mount 4. Bracket mounts between liner and side skirt, stud facing tire. **FIGURE E/F** Position logo-side of flap facing vehicle rear. Fasten SMWASH & 1.5SS#8 into mounts 1 - 3. Install SMWASH & SSLNUT onto mount 5. Align flaps to even ground before tightening fasteners until washers just seat against flap.







**REAR FLAP** Bracket & Hardware 1 x Flap→ BMF99-LR/RR; 1 x .75SP; 1 x 1.5SS#8; 1 x BLKNUT; 1 x EXPANCH; 1 x HXBLT; 5 x

SMWASH; 3 x SSLNUT; 1 x FACTORY FASTENER

Do not fully tighten fasteners until mud flap is completely aligned to vehicle.





### 2022+ SUBARU BRZ/TOYOTA GR86 MUD FLAP INSTALLATION INSTRUCTIONS

FIGURE G Remove factory fastener, then install EXPANCH.

FIGURE H Temporarily remove and retain factory fastener 2.

FIGURE I Gently curve top-end of BMF99-LR/RR to nest against wheel well.







**FIGURE J** Install SMWASH & 1.5SS#8 into BMF99-LR/RR, & .75SP mount 1. Place BMF99-LR/RR between bumper and liner. Reinstall factory fastener into mount 2.

**FIGURE K** Place logo-side of flap against BMF99-LR/RR. Install SMWASH & SSLNUT into mounts 3 – 5 and SMWASH, HXBLT & BLKNUT into mount 6.

FIGURE N Align flaps to even ground before tightening fasteners until washers just seat against flap.











# 2022+ SUBARU BRZ/TOYOTA GR86 MUD FLAP INSTALLATION INSTRUCTIONS

