

IMF63



2018+ Hyundai Kona Mud Flap Installation Instruction

View instructions and photos online www.rallyarmor.com


CARE AFTER INSTALLATION Once installed, the vehicle owner is responsible for the condition of the mud flaps and all costs associated with replacing damaged or lost parts. Warranty covers manufacturer defect on new, never installed parts.

⚠ Watch for blind spots when parking ⚠ Avoid contact with curbs, bumps and objects that can compress the flaps with excessive force. Be sure to check wheel clearances, especially on vehicles equipped with aftermarket wheels and suspensions.

QUESTION ON INSTALLATION? CONTACT US ONLINE www.rallyarmor.com/support

NEED TO PURCHASE REPLACEMENT PARTS? SEND RECEIPT OR PHOTO OF RALLY ARMOR LOGO ON FLAPS TO US www.rallyarmor.com/support

IMPORTANT NOTES



INSTALLATION KIT CONTENTS

QUANTITY	PART	ITEM ID
2	LOCK NUT	SSLNUT
12	WASHER	SMWASH
4	INSERT	INS5
4	ROUND SPACER	.25SP
6	SCREW	1SS
4	LONG SCREW	1.5SS
4	POLYGON CLIP	POLCLP
1	BRACKET LEFT REAR	BMF57-LR
1	BRACKET RIGHT REAR	BMF57-RR
4	BRACKET	BMF63

LOCK NUT
SSLNUT



POLYGON CLIP
POLCLP



SCREW
1SS



LONG SCREW
1.5SS



BRACKET
BMF63



WASHER
SMWASH



ROUND SPACER
.25SP



INSERT
INS5



Recommended Tools Low-profile offset or ratcheting screw driver, 7/16th wrench, flathead screwdriver.

Important Tips Installation should be done on an even surface. **Do not use power tools to tighten hardware.** Hand tools only. Avoid overtightening.

RALLY ARMOR - A BIT ABOUT OUR STANDARD IN MUD FLAPS

Rally Armor mud flaps are fabricated from a high grade polyurethane plastic that is rigorously reviewed for quality and consistency. As with all manufacturing processes, controlled conditions and multiple QC checkpoints minimize major irregularities, however certain very minor surface layer marks appear periodically. These are visual variations that do not affect construction nor do they impede the performance of the flaps. Most matte away as the material ages naturally with continued exposure to the outdoors. Each flap is unique in appearance yet all are equally structurally sound.

2018+ Hyundai Kona Mud Flap Installation Instruction

FRONT MUD FLAP

Bracket & Hardware 1 x Front Flap → 1 x BMF63; 3 x 1SS; 1 x INS5; 3 x SMWASH

Turn steering wheel towards the side you are working on to gain access to the inner wheel well area.

FIGURES A/B Remove factory screws 1, 2 and liner fastener 3.

FIGURE C Remove and discard inner stem of INSERT INS5 prior to installing flush into mounting point.





FIGURE D Logo-side of flap facing rear of vehicle, install two SCREW 1SS with WASHER SMWASH through corresponding bracket mounting points and fender trim. Innermost mount utilizes SCREW 1SS and INSERT INS5. Press head of INSERT to prevent spinning.

Do not tighten completely.

FIGURE E Note only the bottommost and top two out of three holes in the BRACKET are used.

FIGURE F Ensure mud flap is parallel to even ground. **Hand tighten only until washers seated against flap. Adjust coverage as needed.**



REAR MUD FLAP

Bracket & Hardware 1 x Rear Flap → 1 x BMF63; 1 x BMF57-LR/RR; 2 x 1.5SS; 1 x INS5; 2 X .25SP; 3 x SMWASH; 1 x SSLNUT; 2 x POLCLP

FIGURE G Remove factory screws 1 and 2. Remove fastener underneath. Remove original inserts

FIGURE H Pull back liner and replace with POLCLP. Replace Liner

FIGURE I Install REAR BRACKET BMF57-LR/RR against mounting point then lock in place with INSERT INS5. REAR BRACKET is positioned flat against liner.


2018+ Hyundai Kona Mud Flap Installation Instruction



FIGURE J When mounting mud flap, .25SP Spacers mount **behind mud flap** against mounting points 1 and 2 as shown.

FIGURE K Logo-side of flap facing rear of vehicle, install two SCREW 1.5SS with WASHER SMWASH through corresponding BRACKET BMF63 mounting points, .25SP and POLCLP mounting on rear bumper. Innermost mount requires LOCK NUT SSLNUT and WASHER. **Do not tighten completely.**

FIGURE L Ensure mud flap is parallel to even ground. **Hand tighten only until washers seated. Adjust coverage as needed.**



IMF63



2018+ Hyundai Kona Mud Flap Installation Instruction

FRONT REAR MF63 MOUNTING DIAGRAM

